

# Integrated Control Indoor Luminaires Look Up Guide

To use this interactive guide

1. Download PDF file
2. Open with Adobe Acrobat, Chrome or Microsoft Edge
3. Click on the luminaire image to see available NX Lighting Controls Options

Architectural Linear						Downlighting		
Litecontrol						Kurt Versen	Prescolite	
MODx	Bend (88L)	Flow (91L)	Note (67L)	NELO™ (70L, 75L)	SAE100 (101, 102, 103, 104, 105, 106)	Noni™	Liteistry™	LiteFrame®

Recessed						Strip	Surface Mount	
Litecontrol	Columbia Lighting					Lifeshield	Columbia Lighting	Columbia Lighting
Ryvl (55L)	Versify™ (VSY)	Scaler™ (SRP)	LCAT	LCAT-S	TCAT	Kloven (KLO)	MPS	Escalate™ (ESL)

Wall Mount				High & Low Bay Lighting			
Columbia Lighting		Lifeshield		Columbia Lighting			
CWM	Revalume™ (RLW)	Wall 3 (W3B)	Prevent (PVNT)	Echelän (ECH)	PELA	Utilibay™ (UTB2)	Reverie™ (RLB)

Control Option Ordering Logic & Description	Control Option Functionality								Control Option Components
	Networkable	Grouping	Scheduling	Occupancy / Motion	Daylight Harvesting	0-10V Dimming	On/Off Control	Bluetooth® App Programming	
NX Wireless									
NX Connect									
NX Wired									
Independent									

**Default Settings**